<u>SUPERKOP</u>

HOW TO REPLACE THE WATERCUP SEAL

REQUIRED ITEMS

1.Tools

• Flat head screwdriver

2. New Watercup Seal

3-step replacement process:

- 1. Use a flat head screwdriver to carefully to make some slack to pry off the seal from the Watercup. Make sure to not make scratches on the Watercup.
- 2. Remove the seal from the Watercup.
- 3. Install the new seal on the Water cup. Make sure to install it in the correct direction, see picture below.

Well done! Enjoy your espresso!

Superkop, easy-to-handle.





